

# Practical 1: Basic LAN Configuration

**Practical Title:** Create a LAN with switches, routers, and PCs, Assign IP addresses and verify connectivity using ping

**Aim:** To design and configure a basic Local Area Network (LAN) using Cisco Packet Tracer and to verify network connectivity.

## Objective:

- To understand the basic functions of switches and routers.
- To design a simple network topology using Cisco Packet Tracer.
- To manually assign IP addresses to PCs and router interfaces.
- To verify end-to-end connectivity using the `ping` command.

**Theory:** A **switch** is a networking device that connects multiple devices within a LAN. It operates at Layer 2 (Data Link Layer) of the OSI model and uses MAC addresses to forward data packets to the correct destination port. A **router** connects multiple networks and operates at Layer 3 (Network Layer). Its primary function is to determine the best path for data to travel between different networks. It also serves as a **default gateway**, allowing devices within a LAN to access external networks.

A **straight-through cable** is used to connect different devices (e.g., PC to Switch), while a **crossover cable** connects similar devices (e.g., Switch to Switch).

## Steps:

### 1. Create the Network Topology:

- Open Cisco Packet Tracer.
- Drag and drop 2 PCs, 1 Switch (2960), and 1 Router (1841) from the device menu to the workspace.
- Use the "Connections" tool (the lightning bolt icon) and select the copper straightthrough cable.
- Connect PC0 to the Switch, and PC1 to the Switch.
- Connect the Switch to the Router. The topology should look like this:

## 2. Assign IP Addresses:

- **PC0:**

- Click on PC0 > **Desktop** > **IP Configuration**.

- Enter **IP Address:** 192.168.1.2

- Enter **Subnet Mask:** 255.255.255.0

- Enter **Default Gateway:** 192.168.1.1 ○

- PC1:**

- Click on PC1 > **Desktop** > **IP Configuration**.

- Enter **IP Address:** 192.168.1.3

- Enter **Subnet Mask:** 255.255.255.0

- Enter **Default Gateway:** 192.168.1.1 ○

- Router:**

- Click on the Router > **CLI** tab.

Enter the following commands:

```
Router>en
```

```
Router#conf t
```

```
Router(config)#interface fastethernet 0/0
```

```
Router(config-if)#ip address 192.168.1.1 255.255.255.0
```

```
Router(config-if)#no shutdown
```

```
Router(config-if)#exit
```

```
Router(config)#exit
```

```
Router#show ip interface brief
```

## 3. Verify Connectivity:

- Click on PC0 > **Desktop** > **Command Prompt**.

- Type **ping 192.168.1.3** to check connectivity to PC1. A successful ping will show  
**Reply from 192.168.1.3.**

- Type **ping 192.168.1.1** to check connectivity to the router. A successful ping will  
show **Reply from 192.168.1.1.**

**Conclusion:** In this practical, a basic LAN was successfully created using Cisco Packet Tracer. IP addresses were assigned to all devices, and connectivity was verified using the **ping** command, confirming that the network is functioning correctly.

## **Viva / Oral Questions:**

1. What is the difference between a switch and a router?
2. What is the function of a default gateway? What happens if you don't assign one?
3. Explain the purpose of the `ping` command.
4. When do you use a straight-through cable versus a crossover cable?
5. What layer of the OSI model does a router operate on?

## **CLI COMMANDS**

Router>enable

Router#

Router#configure terminal

Enter configuration commands, one per line. End with CNTL/Z.

Router(config)#interface FastEthernet0/0

Router(config-if)#ip address 10.10.10.1 255.255.255.0

Router(config-if)#no shutdown

Router(config-if)#exit

Router(config)#exit

Router#

%SYS-5-CONFIG\_I: Configured from console by console show ip interface brief

Interface IP-Address OK? Method Status Protocol

FastEthernet0/0 10.10.10.1 YES manual up up

## **VERIFY CONNECTIVITY:**

Cisco Packet Tracer PC Command Line 1.0

C:\>PING 10.10.10.3

Pinging 10.10.10.3 with 32 bytes of data:

Reply from 10.10.10.3: bytes=32 time=3ms TTL=128

Reply from 10.10.10.3: bytes=32 time<1ms TTL=128

Reply from 10.10.10.3: bytes=32 time<1ms TTL=128 Reply from 10.10.10.3: bytes=32 time<1ms TTL=128

Ping statistics for 10.10.10.3:

packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milliseconds:

Minimum = 0ms, Maximum = 3ms, Average = 0ms

C:\>ping 10.10.10.1

Pinging 10.10.10.1 with 32 bytes of data:

Reply from 10.10.10.1: bytes=32 time<1ms TTL=255

Reply from 10.10.10.1: bytes=32 time<1ms TTL=255

Reply from 10.10.10.1: bytes=32 time<1ms TTL=255 Reply from 10.10.10.1: bytes=32 time<1ms TTL=255

Ping statistics for 10.10.10.1:

packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milliseconds:

Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\>ping 10.10.10.2

Pinging 10.10.10.2 with 32 bytes of data:

Reply from 10.10.10.2: bytes=32 time=10ms TTL=128

Reply from 10.10.10.2: bytes=32 time=6ms TTL=128

Reply from 10.10.10.2: bytes=32 time<1ms TTL=128 Reply from 10.10.10.2: bytes=32 time<1ms TTL=128

Ping statistics for 10.10.10.2:

Bytes: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milliseconds:

Minimum = 0ms, Maximum = 10ms, Average = 4ms